

# INSTALLING YOUR UPPER RAIL SUPPORT



## STEP 1

Note: Dry-Fit you're Upper-Rail First. Cut & File If Needed.

In the event the Rail feels or fits loose during the Dry-Fit. Apply Adhesive to the Top of Existing Bag-Rail as shown. Our Upper or Top-Rails are of a Pinch-Type System. No Glue Necessary when the Upper-Rail Fits Snug & Tight.



## STEP 2

After The Upper-Rail Prep. Decision Has Been Made. Take the Rail Support & place it (long side in, short side out) Over top of the Existing Bag Rail Area as shown.



## STEP 3

Push Your Upper Top Rail Down Over The Existing Bag-Rail & Leather as shown, making sure of a Snug Fit. Note: Use a Rubber Mallet if there is an Issue by hand. Enjoy Your Bags when done and bolted back on.

**DISCLAIMER:** All Inserts & Supports come in Sets to Fit Both Rt. & Lt. Saddlebags. All leather saddlebags are not stitched the same & due to leather shrinkage will vary in size. Our Product is a One Size Fits All. Cut & File if needed. We recommend applying Leather Softeners & Conditioners before and after Installation. Apply Every 6-Weeks. This will help preserve and keep your Bags from shrinking, cracking, warping and drying-out. Keep your Bags clean, maintained & well preserved @ all times for Longer Lasting Results made for Better Looking Leather Saddlebags. Patent Pending Made In The U.S.A.